





Low-voltage electrical mobile stations for semi-automatic controlled expansion of tubes whose diameter ranges between 3/8" and 2.1/2" (between 9,5 and 63,5 mm).

**The process of tube expansion** in tube sheets using the traditional tube expander must meet **quality, productivity and repeatability requirements** which are essential to successfully pass the strict **pressure tightness tests** the tube sheets undergo in the final testing stage.

To start and control the operation of the tube expander Maus Italia offers a range of fully motorised control systems and accessories, including three main families:

- Portrol (portable)
- Quadrol (semi-automatic)
- Automation (automatic)

Based on our experience we have selected the **control of the torque measured on the expander axis** as the most appropriate reference technology.

Unlike pure dimensional control, in fact, the torque control **can make up for parameter variability** (e.g. tolerances on sheet hole diameter and tube thickness), assuring **reliability**, **repeatability and productivity** to heat exchanger manufacturers.

Thanks to its fifty-year experience in the industry, Maus Italia, a company which always at the cutting edge of research, has designed and manufactured the new electrical stations for semi-automatic tube expansion *Quadrol 90*, deriving from the *Quadrol family*, whose innovative solutions allow tube expansion on an industrial scale

Every component has been redesigned and upgraded, using the most modern and up-to-date technologies, and above all analysing the on-going feedback from our demanding customers; the result is a durable, heavy-duty product for heat exchanger manufacturing workshops.



### **Quadrol 90 standard**

plus ...

- Cheap
- Lightweight
- Easy to disassemble



- Increased operating range on the X axis
- Continuous manual motion along the Y axis
- Motor displacement without gantry crane
- Safe
- Downtime reduction

plus ...



Mobile **semi-automatic** expansion stations accommodating and supporting the **MK low-voltage** 3-phase electrical rolling motors.

The Quadrol 90 stations include the following components:

- F90 V4 electronic expansion controller, the latest version of the successful F90 series, boasting thousands of pieces sold all over the world;
- MK series electrical rolling motor, strong and low-noise, featuring a self-ventilated, low-voltage three-phase motor, with automatic speed variation according to the torque, complete with a four-speed oil-bath gearbox featuring a suspension device mounted on a ball bushing;
- F/308 Hs articulated telescopic shaft, deriving from the previous F/308 series, with innovative design solutions making it reliable, particularly easy to handle as well as accurate and stable at high speeds; it expands the operating range along the X and Y axes and allows motion along the Z axis;
- F/314 Hs and F/317 Hs patented quick couplings, specifically designed to be to be used with the tube expander manufactured by Maus Italia to reduce the vibrations experienced by the operator, particularly when the rotation speed exceeds 400 rpm.
- PE/900 pedal set
- The Quadrol 90 station comes in 3 different versions, according to the Porter series trolley model:
  - Quadrol 90 Sandard with Porter Sandard
    - Quadrol 90 plus
- with **Porter** Dus
- Quadrol 90 exertive with Porter exertive

The **Porter** series **trolleys**, four-wheeled and designed to **support and displace the F90 V4 electronic controller** and the **MK** series **rolling motor**, **dampen the reaction to the torque generated** by the rolling motor, **relieving the operator of this tiring function**.

Their distinctive feature is the extruded aluminium modular structure, combining strength and low weight..

# PANAUS FOOTH OF THE CONTROL OF THE C

High repeatability

Motor-driven rolling motor


vertical

displacement

### Quadrol 90 executive

- Servo driven motion along the Y axis
- Practical
- Motor axis / tube axis alignment
- Cabinets for safe tool and accessory storage.

# Caro setting Quadrol 90 Enter Button set allowing to enter all setting values. ZERO Zero setting 420 AU 420 AU 420 AU 420 AU





### Phase reversal

It allows to immediately reverse rotation without having to operate on the supply cables.





## Usage range amplification

**26 V** greatly reduces the minimum torque value which can be controlled.

**42 V** it allows high-torque processing for large diameter tubes.





### Operability

The automatic mode allows the operator to greatly increase productivity





#### Return time

Time required for the pin to move back and the rollers to return. It allows the operator to withdraw the mandrel from the sheet hole.





### Pausing time

Time elapsing between expansion cycles, allowing the operator to insert the mandrel into the next tube.



Photograph

By the kind SAM

By the kind permission of SAMEC S.p.A.







(Ft Lb)

1-2 approach
2-3 squeezing

torque achievement

45 tube expander release

rotation stopping

# rolling motors with three-phase motor.

### Great increase in sensitiveness

Even compared with the previous M4 series, the **MK** series rolling motors are characterised by the **wide torque adjustment range**, expanding the range of tubes which can be treated.

### Automatic speed variations

The special manufacturing feature progressively and automatically varying speed according to torque allows to select a higher speed value then on the previous version; this results in the following benefits:

A noticeable reduction of cycle time
As the work strain increases the motor rpm decrease.


### Reduced tool wearing

The variation of the rpm according to the strain experiencedby the tube expansion mandrel allows to decrease the motor speed by up to 60%, preventing overheating and the subsequent deterioration of the tools wearing parts.

### Flexibility of use

Thanks to the 4 speed range gearboxes, the MK series rolling motors can optimise the speed range according to work parameters like the ones listed in the table below:

- tube material
- tube diameter and thickness
- roller length
- mandrel model



Setting scale sensitiveness

			MK	800		MK 400				
Mechanical gearbox		I <sup>a</sup>	$\mathrm{II}^{\mathrm{a}}$	$\mathrm{III}^{\mathrm{a}}$	$IV^a$	I <sup>a</sup>	$II^a$	III <sup>a</sup>	IV <sup>a</sup>	
Speed	giri/min (R.P.M)	200	300	540	800	110	170	300	450	
Min. torque	Nm (Ft Lb)	0,30 (0.22)	0,25 (0.18)	0,20 (0.15)	0,15 <i>(0.11)</i>	0,50 (0.37)	0,40 (0.30)	0,30 (0.22)	0,20 (0.15)	
Max. torque	Nm (Ft Lb)	55,00 (40.57)	36,00 (26.55)	20,00 <i>(14.75)</i>	14,00 <i>(10.33)</i>	165,00 <i>(121.70)</i>	114,00 <i>(84.08)</i>	64,00 (47.20)	44,00 <i>(32.45)</i>	
Min tube Ø	mm (inches)	25,40 <i>(1")</i>	19,05 <i>(3/4")</i>	12,70 <i>(1/2")</i>	9,52 (3/8")	38,10 <i>(1.1/2")</i>	25,40 <i>(1")</i>	19,05 (3/4")	15,87 <i>(</i> 5/8")	
Max tube Ø	mm (inches)	38,10 (1.1/2")	31,75 <i>(1.1/4")</i>	22,22 (7/8")	19,05 (3/4")	63,50 (2.1/2")	38,10 (1.1/2")	31,75 (1.1/4")	25,40 <i>(1")</i>	

All listed values are indicative and refer to the 50 Hz supply frequency.

The 60 Hz supply frequency (available as optional) **increases by 20% the specified rpm and decreases by 20% the specified torque values.**The Maus Italia sales service is available to help our customers to identify the most appropriate solution.












**MAUS Quadrol 90** 

# F/314 HS F/317 HS



The latest joints with double guick coupling F/314 Hs and **F/317 HS**, besides allowing to **replace the tube expander extremely** quickly, thanks to an accurate, patented design ensure that the input shaft **F/308** HS is perfectly coaxial with the tube expander mandrel, on the output, reducing any vibration and allowing the operator to more easily insert the running mandrel into the tube.

> **Technical** specifications




# PE/900

**Digital input** remote control pedal set

After placing the Quadrol 90 plus or Quadrol 90 exercise mobile station about 1.2 metre away (as shown in the figure below), the operator will be able to easily insert the tube expander into all the holes arranged inside the coloured area, representing the field which can be reached from an individual position.

Area assuring maximum torque control accuracy and repeatability

Area subject to minimal torque variations, proportional to the inclination of the Cardan joint.



with **Quadrol 90** Dus

1 single position with servo driven

with Quadrol 90 exercity remotely controlled motion







Technical specifications of the *Porter* trolleys and of the *F90V4* controller

### Porter

Porter					
Work axes			Porter Sandard	Porter plus	Porter executive
<b>X</b> axis		Motion	manual sliding	manual sliding	manual sliding
Y axis		Motion	fixed positions	servo manual	motor-driven
Working capac	ity				
Supported torque		Nm (Ft Lb)	250 <i>(184)</i>	250 <i>(184)</i>	250 <i>(184)</i>
Supported weight		Kg (Lb)	150 <i>(330)</i>	150 <i>(330)</i>	150 <i>(330)</i>
Horizontal stroke	X	mm (inches)	600 (23)	1000 (39)	1000 (39)
Vertical stroke	Υ	mm (inches)	4 step 480 (19)	650 <i>(</i> 25 <i>)</i>	650 <i>(</i> 25 <i>)</i>
Dimensions					
Length (depth)	Α	mm (Ft)	500 (1.7)	700 (2.3)	700 (2.3)
Width	В	mm (Ft)	900 (3,0)	1400 <i>(4.6)</i>	1400 <i>(4.6)</i>
Height	C	mm (Ft)	1510 <i>(</i> 5. <i>0</i> )	2030 (6.7)	2030 (6.70)
Weight		Kg (Lb)	40 (89)	81 <i>(179)</i>	113 (250)
Colours			Anodised aluminium	Anodised aluminium	Anodised aluminium
			<b>←</b> B →	B	B

### F90 V4

Supply			F90 V4
Voltage		Volt - Ph	220/400 - 3
Frequency		Hz	50/60
Installed power		Kw	1,6
Motor voltage		٧	26 / 42
Pedal set voltage		V	24
Dimensions			
Length (depth)	Α	mm (Ft)	410 (1.35)
Width	В	mm (Ft)	760 (2.49)
Height	С	mm (Ft)	405 (1.33)
Weight		Kg (Lb)	65 <i>(144)</i>
Degree of protection		IP	55
Colours		RAL	7030 - 7035








Technical specifications of the **MK** motors and of the **F/308 HS** telescopic shaft



### MK

Supply			MK 800	MK 400		
Motor voltage		V	42	42		
Motor power		Kw/A	1,5 / 29	1,5 / 37		
Working capaci	ty					
Speed		(R.P.M)	200-300-540-800	110-170-300-450		
Max torque		Nm (Ft Lb)	55 (40.57)	165 (121.70)		
Min tube Ø		mm (inches)	9,52 (3/8)	15,87 (5/8)		
Max tube Ø		mm (inches)	38,10 <i>(1.1/2)</i>	63,50 <i>(</i> 2. <i>1</i> /2 <i>)</i>		
Recommended telescopic shaft Cod.			F-308 Hs /2	F-308 Hs /3		
Recommended couplings Cod.		Cod.	F/314 Hs	F/317 Hs		
Adapter		C.M.	3	3		
Dimensions						
Gearbox Ø	Α	mm (Ft)	180,0 <i>(0.59)</i>	180,0 <i>(0.59)</i>		
Width	В	mm (Ft)	608,5 <i>(1.99)</i>	608,5 <i>(1.99)</i>		
Height	С	mm (Ft)	272,0 <i>(0.89)</i>	272,0 <i>(0.89)</i>		
Weight		Kg (Lb)	32,0 (71)	32,0 (71)		
Degree of protection		IP	55	55		
Certified noise test		Db	35	35		
Colours		RAL	9005 - 7030 - 7035	9005 - 7030 - 7035		



All listed values are indicative and refer to the 50 Hz supply frequency.

The **60 Hz** supply frequency (available as optional) **increases by 20% the specified rpm and decreases by 20% the specified torque values.**The Maus Italia sales service is available to help our customers to identify the most appropriate solution.

### F/308 HS

F/308 Hs		Handle A	Telescopi	Telescopic range		Extensibility		Max. torque		Weight	
Model	N	mm inches	mm	inches	mm	inches	Nm	Lb Ft	Kg	Lb	mm
<b>F-308 Hs-2</b> /b	3	205 8.1	650÷1060	25.6 <del>:</del> 41.7	410	16.1	70	51	5,4	11.90	12
F-308 HS-3	3	225 8.9	650÷1060	25.6 <del>:4</del> 1.7	410	16.1	180	132	7,9	17.41	18
<b>F-3</b> 08 нs-3 <b>L</b>	3	225 8.9	850÷1460	33.5÷57.5	610	24.0	180	132	8,9	19.62	18

\* Version with extra extensibility for use with mandrels whose length exceeds 500mm (19,7")





Technical specifications of the **F/314 HS** and **F/317 HS** couplings





• For any further items please refer to the "Accessories" catalogue



